


# VIGOUR


Pure Lebenskraft im Bad

## Montage- und Bedienanleitung


- CZ** Návod k instalaci a k použití
- DK** Monterings- og betjeningsvejledning
- E** Instrucciones de montaje y de manejo
- F** Instructions de montage et mode d'emploi
- GB** Installation and operating instructions
- H** Szerelési és használati utasítás
- I** Istruzioni di montaggio e per l'uso
- NL** Montagehandleiding en Gebruiksaanwijzing
- NO** Monterings- og bruksanvisning
- P** Manual de montagem e utilização
- PL** Instrukcja montażu i obsługi
- RU** Руководство по монтажу и эксплуатации
- S** Installations- och skötselanvisning
- SK** Návod na montáž a obsluhu




VO2FW  
VO2FWIS



WH2ITENFW  
WH2ITENFWIS




DE2FW  
DE2FWIS



CL2FW  
CL2FWIS



GRFW  
GRFWSM  
GRFWIS  
GRFWISSM



DE2SFW  
DE2SFWSM  
DE2SFWIS  
DE2SFWISSM

DIN EN 806  
DIN EN 1717  
DIN 1988  
Global Standards

9 62 951/02

VIGOUR GmbH  
Bergholzstraße 3  
D-12099 Berlin

www.vigour.de

# VIGOUR

**!**

°C / °F

max. 70 °C / 158 °F

✓ 60 °C / 140 °F

min. 10 °C / 50 °F

✓ 3 bar / 43,5 psi

min. 1 bar / 14,5 psi

max. 10 bar / 145 psi

3 min.

max. 70 °C / 158 °F

**1.**

**2.**

**3.**

**4.**

